


# CC2525

## Box List



Item No: CC2525		Worker	Q C	ganger
Box	Quantity			
Part name	Quantity			
Front wire(前网)	1pcs			
Top wire(盖网)	1pcs			
Left side wire(No leg) (左侧网/无脚)	1pcs			
Right side wire(With leg) (右侧网/有脚)	1pcs			
Assembly Instructions(包装图)	1pcs			
Upper perch(上棍)	1pcs			
Bottom perch(下棍)	1pcs			
Grill(密网)	1pcs			
"U" Frame (U型支架)	1pcs			
Stairs(梯架)	1pcs			
Tray (盆)	2pcs			
Tube (方管)	2pcs			
Toy hook(No include) (玩具钩)	1pcs			
Wheels(2寸8厘脚轮)	4pcs			
Feeders(4寸杯)	4pcs			
Holder(4寸合圈)	2pcs			
Screw bag(螺丝包)	1pcs			

1. Screw 3x wheels onto bottom of front wire & 1x wheel onto bottom of back wire(with leg);
2. Attach front 、 2x back wire together with screws to form a body;
3. Attach the 2x tube to the front & back wire together with screws;
4. Slide top wire onto top of body;
5. Slide tray into the body from the front wire;
6. Slide tray and grill into the body from part B;
7. Assembly stairs and toy hook stand onto the top of the body;
8. Open the front door and put perch from left to right inside the body;
9. Open the dish door and put the dish into the holders;
10. Fixup all the screws.